### § 250.1159

do not object and proceed with a decision.

#### PRODUCTION RATES

# § 250.1159 May the Regional Supervisor limit my well or reservoir production rates?

(a) The Regional Supervisor may set a Maximum Production Rate (MPR) for a producing well completion, or set a Maximum Efficient Rate (MER) for a reservoir, or both, if the Regional Supervisor determines that an excessive production rate could harm ultimate recovery. An MPR or MER will be based on well tests and any limitations imposed by well and surface equipment, sand production, reservoir sensitivity, gas-oil and water-oil ratios, lo-

cation of perforated intervals, and prudent operating practices.

(b) If the Regional Supervisor sets an MPR for a producing well completion and/or an MER for a reservoir, you may not exceed those rates except due to normal variations and fluctuations in production rates as set by the Regional Supervisor.

# FLARING, VENTING, AND BURNING HYDROCARBONS

## § 250.1160 When may I flare or vent gas?

(a) You must request and receive approval from the Regional Supervisor to flare or vent natural gas at your facility, except in the following situations:

Additional requirements

The volume of gas flared or vented may not exceed the

#### Condition

- (1) When the gas is lease use gas (produced natural gas which is used on or for the benefit of lease operations such as gas used to operate production facilities) or is used as an additive necessary to burn waste products, such as H<sub>2</sub>S.
- (2) During the restart of a facility that was shut in because of weather conditions, such as a hurricane.
- (3) During the blow down of transportation pipelines downstream of the royalty meter.
- (4) During the unloading or cleaning of a well, drill-stem testing, production testing, other well-evaluation testing, or the necessary blow down to perform these procedures.
- (5) When properly working equipment yields flash gas (natural gas released from liquid hydrocarbons as a result of a decrease in pressure, an increase in temperature, or both) from storage vessels or other low-pressure production vessels, and you cannot economically recover this flash gas.
- (6) When the equipment works properly but there is a temporary upset condition, such as a hydrate or paraffin plug.

- amount necessary for its intended purpose. Burning waste products may require approval under other regulations.
- Flaring or venting may not exceed 48 cumulative hours without Regional Supervisor approval.
- (i) You must report the location, time, flare/vent volume, and reason for flaring/venting to the Regional Supervisor in writing within 72 hours after the incident is over.
- (ii) Additional approval may be required under subparts H and J of this part.
- You may not exceed 48 cumulative hours of flaring or venting per unloading or cleaning or testing operation on a single completion without Regional Supervisor approval.
- You may not flare or vent more than an average of 50 MCF per day during any calendar month without Regional Supervisor approval.
- (i) For oil-well gas and gas-well flash gas (natural gas released from condensate as a result of a decrease in pressure, an increase in temperature, or both), you may not exceed 48 continuous hours of flaring or venting without Regional Supervisor approval.
- (ii) For primary gas-well gas (natural gas from a gas well completion that is at or near its wellhead pressure; this does not include flash gas), you may not exceed 2 continuous hours of flaring or venting without Regional Supervisor approval.
- (iii) You may not exceed 144 cumulative hours of flaring or venting during a calendar month without Regional Supervisor approval.
- (i) For oil-well gas and gas-well flash gas, you may not exceed 48 continuous hours of flaring or venting without Regional Supervisor approval.
- (ii) For primary gas-well gas, you may not exceed 2 continuous hours of flaring or venting without Regional Supervisor approval.
- (iii) You may not exceed 144 cumulative hours of flaring or venting during a calendar month without Regional Supervisor approval
- (iv) The continuous and cumulative hours allowed under this paragraph may be counted separately from the hours under paragraph (a)(6) of this section.

(7) When equipment fails to work properly, during equipment maintenance and repair, or when you must relieve system pressures.